

USING YOUR TENSION BOX



When using your tension box you can clamp the assembly to any work surface or attach the box to our own doubling stand/cone holder using a bolt through the hole in the bottom.



The pegs can be oriented either horizontally or vertically as best fits your application. The thread(s) may be routed through the screw eye at the beginning or end of the tension box, depending on your function. When used with our doubling stand/cone holder, the screw eye is at the end of the tension box as the threads are already controlled by the grommet at the top of the doubling stand/cone holder.

Use as many or as few of the pegs as necessary to achieve the tension you desire. It is possible to increase the tension by taking a complete turn around one of the pegs. If you wrap the first peg you get an increase in tension; if you wrap the last peg you get a GREAT increase in tension.